



**HOW TO**

**Change the side edge to a  
side-access-ramp**

## Table of contents

1	Introduction	3
2	Preparation.	3
2.1	Parts	<b>Fejl! Bogmærke er ikke defineret.</b>
2.2	Tools	<b>Fejl! Bogmærke er ikke defineret.</b>
3	Step by step	4
3.1	Demount the side edge	4
3.2	Installation of the side-access-ramp	5

## 1 Introduction

If you for some reason must change the side edge to a side-access-ramp, the description below is explaining how you must do this operation.

## 2 Preparation.

Before you install the side-access-ramp please read these instructions carefully. Check that you have all the necessary parts and tools to install the side-access-ramp.

**NOTE!** The platform frame does not have pre-drilled holes for mounting the side-access-ramp (see pictures for drilling the holes on the following pages.)

### 3 Step by step

#### 3.1 Demount the side edge

Use a screwdriver to remove the 2 UMBRAKO screws that is holding the side edge, see picture below:



Flaps holding the side edge is removed:



### 3.2 Installation of the side-access-ramp

Install the Bowden-cable on the ramp as shown on below picture:



Hold the side-access-ramp in a 90° angle and tighten the two 6 mm socket screws with a 3 mm Allen key.



Adjust the spring:



Drill holes and make thread for the fastening of the spring:



Install the spring:



The installation of the side-access-ramp is now completed, and you can put the platform back together again. We suggest that you make a test drive with the lift to check if the side-access-ramp is working properly.

(We reserve the right to make alterations on the lift)