




ELECTRIC DIAGRAM

FOR HANDI-LIFT 6

Table of contentse


1	EA6 (Micro-1)	3
2	EA6 (Micro Smart)	4
3	EA6-H2 Page 1	5
4	EA6-H2 page 2	6
5	EA6-H3 page 1	7
6	EA6-H3 page 2	8
7	EA6-H3B page 1	9
8	EA6-H3B page 2	10
9	EA6-H5 page 1	11
10	EA6-H5 Page 2	12
11	EA6 Control and supply	13

1 EA6 (Micro-1)




CAMA aps. ELLEHAMMERVEJ 6, 9900 FREDERIKSHAVN.
Telefon: +45 98 43 01 22 - Telefax: +45 98 42 08 02

2 EA6 (Micro Smart)




3 EA6-H2 Page 1



4 EA6-H2 page 2


No:	Old No:	Description:	Spare-part:
S1		Position Control	6-4060-11
S2		Position Control	6-4060-11
S3		Reset	0-8002-4
S4		Safety Gear	6-8010-13
S5		Overspeed Governor	6-8010-14
S6	SE	Switch for chain	6-8010-17
S7	KNE	Switch for upper ramp	6-8010-5
S8	ULE1	Lower platform plate switch	6-8010-7
S9	ULE2	Lower Platform switch	6-8010-8
S10	ULE3	Lower Platform switch	6-8010-8
S11	ULE4	Lower Platform switch	6-8010-7
S12	KOE	Switch for lower ramp	6-8010-6
S13	BE1	Lower Barrier arm switch	6-8010-3
S14	BE2	Upper Barrier arm switch	6-8010-4

No:	Old No:	Description:	Spare-part:
S15	LE1	Lower Platform switch	6-8010-1
S16	LE2	Upper Platform switch	6-8010-2
S20		Joystick	6-8002-8
S21		Emergency stop.	0-8002-2
S22		Emergency Call	6-8003-5
S23		Switch for safety plate	6-8010-18
S24		Switch for safety plate	6-8010-18
S25		Sensitive side edge switch	6-8010-16
S26		Sensitive side edge switch	6-8010-16
S27		Sensitive side edge switch	6-8010-16
S28		Sensitive side edge switch	6-8010-16
S29		Lower platform plate switch	0-8002-5



EA6-H2


5 EA6-H3 page 1



6 EA6-H3 page 2


No:	Old No:	Description:	Spare-part:
S1		Position Control	6-4060-11
S2		Position Control	6-4060-11
S3		Reset	0-8002-4
S4		Safety Gear	6-8010-13
S5		Overspeed Governor	6-8010-14
S6	SE	Switch for chain	6-8010-17
S7	KNE	Switch for upper ramp	6-8010-5
S8	ULE1	Lower platform plate switch	6-8010-7
S9	ULE2	Lower Platform switch	6-8010-8
S10	ULE3	Lower Platform switch	6-8010-8
S11	ULE4	Lower Platform switch	6-8010-7
S12	KOE	Switch for lower ramp	6-8010-6
S13	BE1	Lower Barrier arm switch	6-8010-3
S14	BE2	Upper Barrier arm switch	6-8010-4

No:	Old No:	Description:	Spare-part:
S15	LE1	Lower Platform switch	6-8010-1
S16	LE2	Upper Platform switch	6-8010-2
S20		Joystick	6-8002-8
S21		Emergency stop.	0-8002-2
S22		Emergency Call	6-8003-5
S23		Switch for safety plate	6-8010-18
S24		Switch for safety plate	6-8010-18
S25		Sensitive side edge switch	6-8010-16
S26		Sensitive side edge switch	6-8010-16
S27		Sensitive side edge switch	6-8010-16
S28		Sensitive side edge switch	6-8010-16
S29		Lower platform plate switch	0-8002-5



EA6-H3


7 EA6-H3B page 1



8 EA6-H3B page 2


No:	Old No:	Description:	Spare-part:
S1		Position Control	6-4060-11
S2		Position Control	6-4060-11
S3		Reset	0-8002-4
S4		Safety Gear	6-8010-13
S5		Overspeed Governor	6-8010-14
S6	SE	Switch for chain	6-8010-17
S7	KNE	Switch for upper ramp	6-8010-5
S8	ULE1	Lower platform plate switch	6-8010-7
S9	ULE2	Lower Platform switch	6-8010-8
S10	ULE3	Lower Platform switch	6-8010-8
S11	ULE4	Lower Platform switch	6-8010-7
S12	KOE	Switch for lower ramp	6-8010-6
S13	BE1	Lower Barrier arm switch	6-8010-3
S14	BE2	Upper Barrier arm switch	6-8010-4

No:	Old No:	Description:	Spare-part:
S15	LE1	Lower Platform switch	6-8010-1
S16	LE2	Upper Platform switch	6-8010-2
S20		Joystick	6-8002-8
S21		Emergency stop.	0-8002-2
S22		Emergency Call	6-8003-5
S23		Switch for safety plate	6-8010-18
S24		Switch for safety plate	6-8010-18
S25		Sensitive side edge switch	6-8010-16
S26		Sensitive side edge switch	6-8010-16
S27		Sensitive side edge switch	6-8010-16
S28		Sensitive side edge switch	6-8010-16
S29		Lower platform plate switch	0-8002-5



EA6-H3B


9 EA6-H5 page 1



10 EA6-H5 Page 2

No:	Description:
S1	Position Control
S2	Position Control
S3	Reset
S4	Safety Gear
S5	Overspeed Governor
S6	Switch for chain
S7	Switch for upper ramp
S8	Lower platform plate switch
S9	Lower Platform switch
S10	Lower Platform switch
S11	Lower Platform switch
S12	Switch for lower ramp
S13	Lower Barrier arm switch
S14	Upper Barrier arm switch

No:	Description:
S15	Lower Platform switch
S16	Upper Platform switch
S20	Joystick
S21	Emergency stop.
S22	Emergency Call
S23	Switch for safety plate
S24	Switch for safety plate
S25	Sensitive side edge switch
S26	Sensitive side edge switch
S27	Sensitive side edge switch
S28	Sensitive side edge switch
S29	Lower platform plate switch



EA6-H5

11 EA6 Control and supply

