




**FAULTFINDING  
FOR HANDI-LIFT 7 (H5/H6)**

## **Table of contents**

1	EA7 page 1	2
2	EA7 page 2	3
3	EA7 page 3	4


### EA7 page 1




#### FUSES

F1	Control current	50mA
F2	Platform + barrier	6,3A
F3	Barrier motor	3,15A
F4	Platform motor	8A

**EA7 page 2**



**EA7 page 3**



\* Joystick will be activated at the same