






TOP VIEW



BOTTOM VIEW



When you install Handi-Lifts type 7 delivered with remote control boxes or remote control only make sure that the main supply cable to the lift has jumped wire number 5 and 6



When you install Handi-Lifts type 7 delivered with remote control boxes or remote control only make sure that the main supply cable to the lift has jumped wire number 5 and 6

SLAVE CONTROL BOX

